HYDRANT RENTAL



METER HOOK UP W\APPROVED AIRGAP

RULES AND REGULATIONS

- **DO NOT CHAIN EQUIPMENT TO HYDRANT**
- **EQUIPMENT CANNOT BE LEFT ON HYDRANT OVERNIGHT**
- **SOMEONE MUST BE ONSITE WHILE EQUIPMENT IS ATTACHED TO HYDRANT**
- **HYDRANT PERMIT TAG MUST BE CURRENT AND CLEARLY DISPLAYED WHILE USING HYDRANT**
- **IMPROPER USE OF EQUIPMENT WILL RESULT IN A FINE OF $5,000 PER INCIDENT**
- **PERMITS ARE ISSUED FOR A MAXIMUM OF 90 DAYS AND MAY INCLUDING ONE TIME EXTENSIONS**
- **FOR A ONE TIME EXTENSION OF PERMIT CALL: 503-823-8961**

- **FOR ANY QUESTIONS OR PROBLEMS CALL: (503) 823-8961**
-
- **FOR ALL EMERGENCIES CALL (503) 823-4874**

NOTE: NON COMPLIANCE WILL RESULT IN A $5,000 FINE PER INCIDENT

INSTRUCTIONS

- **AN APPROVED CHAPMAN GATE VALVE AND SPANNER WRENCH MUST BE USED ON EACH HYDRANT OUTLET**

  1.) REMOVE HYDRANT CAP

  2.) INSTALL CHAPMAN IN CLOSED POSITION

  3.) CHECK OUTLET CAPS. TIGHTEN IF NECESSARY.

  4.) TO OPEN HYDRANT (TURN ONLY, TWELVE COMPLETE TURNS COUNTER-CLOCKWISE)

  5.) CONTROL THE FLOW OF WATER WITH THE CHAPMAN VALVE, NOT THE HYDRANT STEM

  ~~~~~~

- **IF HYDRANT MALFUNCTIONS IN ANY MANNER, VIBRATES WHEN FLOWING, OR WATER BOILS FROM THE BASE OF THE HYDRANT DISCONTINUE USE IMMEDIATELY AND CALL: (503) 823-4874**
  ~~~~~~

Hydrant Shut Down Procedures

- **1. Close the Chapman Valve.**
- **2. Shut down hydrant by turning in a clockwise direction 12 complete turns.**
- **3. Remove the Chapman Valve and check inside the hydrant barrel, to make sure the water level is dropping, before replacing cap.**
- **4. If water is still flowing, the hydrant is not fully shut off, turn in 1/8 of a turn increments until fully closed.**
- **5. DO NOT OVERTIGHTEN THE HYDRANT WHEN CLOSING.**