


**BICYCLE CROSSING SIGN DETAIL**  
(NOT TO SCALE)




**W3262 -BIKE PED SYMBOL**


REPLACE W11-2 WITH W3262  
IF CROSSING IS DESIGNED FOR  
BICYCLIST/PEDESTRIAN



**PEDESTRIAN CROSSING SIGN DETAIL**  
(NOT TO SCALE)



**RECTANGULAR RAPID FLASH BEACON  
(AC POWERED) POLE ASSEMBLY DETAIL**  
(WITH CONTROLLER AND SERVICE CABINET)



**RECTANGULAR RAPID FLASH BEACON  
(AC POWERED) POLE ASSEMBLY DETAIL**  
(WITHOUT CONTROLLER AND SERVICE CABINET)  
(SEE PLAN IF SIGNS & RRFB'S ARE ON BOTH SIDE OF THE POLE)

The selection and use of this Standard Drawing, while designed in accordance with generally accepted engineering principles and practices, is the sole responsibility of the user.

**BUREAU OF TRANSPORTATION  
CITY OF PORTLAND, OREGON**  
*Steve Tom*  
Chief Engineer

Standard Drawing Title  
**RECTANGULAR RAPID FLASH BEACON  
(AC POWERED)  
POLE ASSEMBLY DETAIL**

Note:  
All material and workmanship shall be in accordance with the City of Portland Standard Construction Specifications.

Effective Date: 05-10-2016

Calc. Book No.:

Baseline Report Date:

Standard Drawing No.

**P-639**