


Phase 1: Install Restrained Pipe Section and Thrust Collar



DO NOT EXCAVATE CLOSER THAN 3 times the Width of the thrust collar

Phase 2: Water Bureau Post Contract Work Plan

Construction Sequencing Notes

Phase 1: Advanced Thrust Collar Installation

1. Perform shut down on existing main.
2. Install fully restrained pipe section. Pipe length between thrust collar and tie-in connection shall be minimum 3 times thrust collar width.
3. Place concrete thrust collar per Std Drawing P-795.
4. Backfill and compact.
5. Do not close gate valve until concrete reaches a compressive strength of 3,000 psi.


Phase 2: Tie-in

1. If there is excavation work by others within 50 feet of thrust collar, do not begin tie-in work without contacting Project Engineer for approval to proceed.
2. Do not excavate closer than 3 times the width of thrust collar.
3. Install tie-in with fully restrained pipe section.

General Note:

1. Thrust collar is designed to address connection to existing unrestrained pipe section. Joint restraint for tie-in to be designed by Project Engineer of Record.

Plot Date: 11/2/2017 1:20:41 PM Filename: J:\Engineering\CAD\Standards\Working_Vaults\VP-795_UrbanThrustBlok.dgn

<p>The selection and use of this Standard Drawing, while designed in accordance with generally accepted engineering principles and practices, is the sole responsibility of the user.</p> <p>Note: All material and workmanship shall be in accordance with City of Portland Standard Construction Specifications.</p>	 <p>PORTLAND WATER BUREAU CITY OF PORTLAND, OREGON</p> <p><i>[Signature]</i> Chief Engineer</p>	
	<p>Standard Drawing Title</p> <p align="center">Concrete Thrust Collar Sequencing Plan</p>	
	<p>Effective Date</p> <p>Calc. Book No.</p> <p>Baseline Report Date</p>	<p>11/02/2017</p> <p>PWB 1</p> <p>11/02/2017</p>